



The RZR Turbo Blow Hole Install Instructions



1. Locate the clutch housing intake tube and loosen clamp on clutch cover. Then remove Intake Tube from both intake and clutch cover.



2. Using a silver or white marker, mark section 6 of the tube as shown in picture (Count Sections from clutch cover side towards intake side) Using a Razor blade or knife, carefully cut out Section 6 of the Intake Tube as shown.



3. Install the Blow Hole and clamps as shown. Slide Intake Tube onto the Blow Hole and up till it reaches the black guidelines. Leave clamps loose for adjustments.



4. Install the Intake Tube back onto the machine and adjust tubes so wiring harness is towards the machine and logo is facing out. Tighten all clamps.

MTNTKperformance.com





5. Route wiring harness along the bed so it is up and out of the way. Plug into factory taillight connector as shown. Make sure the wires will not rub or chafe on any sharp edges. Use zip ties to secure wiring harness.



