

MTNTK PERFORMANCE

The RZR 900 TRAIL | S | XC | 1000s HIGH FLOW INTAKE TUBE INSTALL INSTRUCTIONS



1. Remove access panel from RZR and remove the center console as shown. This requires the removal of the eight torx head screws on the front and back of the cover.



2. Locate the intake tube on the driver's side of the RZR and directly above the clutch cover. Remove the clamps located on both ends of the intake tube. Keep these as they will be used to install the new High Flow Intake Tube.



3. Locate the small breather hose secured by a hose clamp and remove. This line will be reattached onto the new intake tube.



4. Place the new intake tube in the stock location as shown. Secure using the stock clamps. Install the breather hose onto the intake and tighten using stock clamps.

MTNTKperformance.com

***Disclaimer:** All MTNTK Performance Products are designed to offer unmatched reliability and dependability while adding horsepower and performance. They do not however offer any sort of gains from engines or machines that have preexisting problems or conditions. MTNTK Performance is not liable for any malfunctions, mishaps, engine problems, or any other unforeseen problems that may occur after purchasing this or any other MTNTK Performance Product.*

Kit Contents:

1 – High Flow Intake Tube Assembly

MTNTKperformance.com